DI3D9-02


DTC	RrDEF, M 1	Front Air Mix Damper Control Servo- motor Circuit
-----	------------	--

# **CIRCUIT DESCRIPTION**

The front air mix damper control servomotor is controlled by the A/C control assembly and moves the air mix damper to the desired position.


Blinking lilght	Detection Item	Trouble Area
RrDEF M1	Air mix damper position sensor value does not change even if A/C control assembly operates air mix damper control servomotor.	Front air mix damper control servomotor. Front air mix damper position sensor. Harness or connector between front air mix control servomotor and A/C amplifier A/C amplifier

# **WIRING DIAGRAM**



# **INSPECTION PROCEDURE**

1 Check front air mix damper control servomotor.



### **PREPARATION:**

Remove front air mix damper control servomobor.

#### CHECK:

Connect positive (+) lead to terminal 3(6) and negative (-) lead to terminal 2(7).

(): RHD

## OK:

The lever turns smoothly to Hot side.

### **CHECK:**

Connect positive (+) lead to terminal 2(7) and negative (-) lead to terminal 3(6).

(): RHD

## OK:

The lever turns smoothly to Cool side.

NG

Replace front air mix damper control servomotor assembly.

OK

2

Check harness and connector between A/C amplifier and front air mix damper control servomotor assembly (See page IN-35).

NG

Repair or replace harness or connector.

ОК

Check and replace A/C amplificer.